


Saga™ Logger

Handling the Saga standard logger

Handling the Saga Standard logger

Do's

- ✓ Handle the device with care to avoid damage to its components.
- ✓ Handle the USB connector carefully, and always close it back after charging.
- ✓ Write only on the designated blank spaces (i.e., on the blank top label or the Logger Box, if applicable).
- ✓ Always follow the charging instructions when charging the device.
- ✓ Follow best practices for storing devices.
- ✓ Use the device in shipment conditions within the standard operating temperature range (-20°C to +50°C).
- ✓ Attach the device securely during shipment to prevent damage from impacts.
- ✓ Use a soft, dry cloth for cleaning (if necessary).



Don'ts

- ✗ Peel off, scratch, or write on the labels that contain information about the device.
- ✗ Add your own labels or stickers, or leave pen marks on the device.
- ✗ Use abrasive cleaners or solvents for cleaning.
- ✗ Use sharp objects around the device.
- ✗ Perform any unauthorized modifications or disassembly.
- ✗ Press buttons with excessive force.
- ✗ Submerge in water.
- ✗ Let the device operate in the extended operating temperature range (-30°C to -20°C and +50°C to +70°C) for longer than 6 hours.
- ✗ Expose the device to extreme temperatures (below -30°C or above 70°C).



Further details can be found on <https://support.controlant.com/>